







3/4 or you may press the next or previous buttons on the booth's table. box or by typing the number of a different candidate. Click here to listen to instructions on your headphones. You may change your vote by clicking in a different Click here to darken the screen Go back one page by clicking here Click here to finish voting Continue voting by clicking here typing the number displayed next to the candidate's name. FIG. 3b <u>~96</u> Vote for only one by placing an x in the box to the left of the candidate's name or by For President of the United States 12 84 X George Washington ☐ Thomas Jefferson 🗌 John Adams ☐ Write-in

CHOICE1 CHOICE 2 | ... CHOICE N APPARATUS IDENTIFICATION | DATE DATE CHOICE1 CHOICE 2 000 CHOICE N APPARATUS IDENTIFICATION DATE CHOICE1 CHOICE 2 | . . . | CHOICE N | APPARATUS IDENTIFICATION | RECORD 2 | BALLOT SEQUENCE NUMBER | PAGE RECORD n | BALLOT SEQUENCE NUMBER | PAGE PAGE RECÒRD 1 BALLOT SEQUÈNCE NUMBER FIG. 4



